

ROLLANT		520 RC	520 RF	520 R	620 RC	620 RF
Hitching						
PTO shaft speed	rpm	540	540	540	540	540
Single wide-angle drive shaft with freewheel and cam control		●	○	○	●	○
Single wide-angle universal drive shaft with shear bolt coupling		●	●	●	●	●
Power requirement	hp	80	80	80	80	80
Pick-up						
Width	m	2.10	2.10	1.85	2.10	2.10
DIN pick-up width	m	1.90	1.90	1.65	1.90	1.90
Simple spool valve for raising the pick-up and the knives		●	–	–	●	–
Number of tines per row		32	32	28	32	32
Tine spacing	mm	70	70	70	70	70
Pick-up castor guide wheels		Fixed (oscillating ○)				
Crop feed						
Forced crop feed with		ROTO CUT	ROTO FEED	Feed rake	ROTO CUT	ROTO FEED
Number of knives		14	–	–	7	–
Hydraulic connection						
Simple spool valve for raising the pick-up		●	●	●	●	●
Dual-acting spool valve for tailgate rams		●	●	●	●	●
Bale chamber						
Number of compaction rollers		16	16	16	17	17
MAXIMUM PRESSURE SYSTEM II		○	○	–	–	–
Automatic dual twine wrapping		●	●	●	●	●
Net wrapping ROLLATEX		●	●	●	●	●
Number of twine reels in the twine box		6	6	6	6	6
Number of net rolls		2	2	2	2	2
Adjustable baling pressure on the machine		●	●	●	●	●
Bale ramp		○	○	○	○	○
Automatic chain lubrication		●	●	●	●	●
Bale chamber dimensions						
Width	m	1.20	1.20	1.20	1.22	1.22
Diameter	m	1.25	1.25	1.25	1.50	1.50
Operation						
OPERATOR		●	●	●	●	●
Tyres						
11.5/80-15.3 8PR		●	●	●	●	●
15.0/55-17 10PR		○	○	○	○	○
19.0/45-17 10PR		○	○	○	○	○
Running axle		●	●	●	●	●
Air brakes		○	○	○	○	○
Hydraulic brakes		○	○	○	○	○
Active hydraulic braking system		○	○	○	○	○
Dimensions and weights						
Length	m	4.70	4.70	4.70	5.08	5.08
Width	m	2.50	2.50	2.50	2.47	2.47
Height	m	2.30	2.30	2.30	2.97	2.97
Weight	kg	2990	2685	2685	3470	3250

CLAAS continually develops its products to meet customer requirements. This means that all products are subject to change without notice. All descriptions and specifications in this brochure should be considered approximate and may include optional equipment that is not part of the standard specifications. This brochure is designed for worldwide use. Please refer to your nearest CLAAS dealer and their price list for local specification details. Some protective panels may have been removed for photographic purposes in order to present the function clearly. To avoid any risk of danger, never remove these protective panels yourself. In this respect, please refer to the relevant instructions in the operator's manual.

● Standard ○ Optional – Not available